



SŁUPY PROSTE DO MONTAŻU SYGNALIZATORÓW (SRP)



Stopa słupa dla posadowienia (F)

Typ Słupa	H1 [m]	H2 [m]	D [mm]	E [mm]	F [mm]	Śruby kotwiące	Posadowienie
SRP 15 - 1	1,5	1,0 ÷ 1,2	108 lub 114	280	200	M18 / M20	G/ F/ ZK/
SRP 20 - 1	2,0						
SRP 25 - 1	2,5						
SRP 30 - 1	3,0						
SRP 35 - 1	3,5						
SRP 40 - 1	4,0						
SRP 45 - 1	4,5						